



- CONCRETE FOUNDATION WALL
- SOLDIER PILE
- PRECON
(FABRIC FACE TO
CONCRETE)
- MEL-DRAIN
(FABRIC FACE TO
PLYWOOD)
- TIMBER LAGGING
- REMOVE RELEASE PAPER FROM
SELVAGE EDGE AND SET NEXT
SHEET INTO THE SELVAGE EDGE
- SOIL

W.R. MEADOWS, INC.

300 Industrial Drive
 Hampshire, IL 60140-0338
 1-800-342-5976
 www.wrmeadows.com

SKETCH: BLIND SIDE
 SOLDIER PILES
 PRECON
 PLAN VIEW AT LAP

SKETCH NO: PRECON - 28

DATE: 07/11/2013