



DATA SHEET NO. 6055-512

DETAIL TAPE V

Polymeric Waterproofing Membrane

DESCRIPTION

DETAIL TAPE V is a polymeric waterproofing membrane with a dual release paper. It is nominally 60 mils thick and is nominally 304.8 mm (12") wide.

USES

DETAIL TAPE V can be used as a detailing option with PRECON® and HYDRASTOP™ SA from W. R. MEADOWS in vertical applications.

FEATURES/BENEFITS

- Self-adhesive
- Easy to apply with removable release paper
- Provides a secure, durable bond
- Compatible with both PRECON and HYDRASTOP SA

PACKAGING

304.8 mm (nominal) x 15.24 m (12" x 50') Rolls, 4/Carton.

APPLICATION

Application Method (PRECON)... Application requires the use of MEL-DRAIN™ from W. R. MEADOWS. Install MEL-DRAIN up against a soil retention system according to published installation instructions. Ensure the backside of MEL-DRAIN has been cleaned and there is no residue that will inhibit the bond of DETAIL TAPE V. Remove the release paper on one side of the tape and roll press this tape onto MEL-DRAIN. On the side of the tape facing out, remove the release paper on the one side of the tape, exposing 152.4 mm (6") of the rubberized asphalt, and then apply the PLASMATIC® CORE side of the PRECON into this and roll press into place. Following this, remove the remaining release paper on the tape and apply the subsequent roll of PRECON into this area, making sure that both rolls are butted together. Roll press this into place. Following that, apply a 304.8 mm (12") band of POINTING MASTIC from W. R. MEADOWS onto this overlap at a thickness of approximately 60 mils, and embed DETAIL FABRIC from W. R. MEADOWS into this.

Application Method (HYDRASTOP SA) ... Application requires the use of MEL-DRAIN from W. R. MEADOWS. Install MEL-DRAIN up against a soil retention system according to published installation instructions. Ensure the backside of MEL-DRAIN has been cleaned and there is no residue that will inhibit the bond of DETAIL TAPE V. Remove the release paper on one side of the tape and roll press this tape onto MEL-DRAIN. On the side of the tape facing out, remove the release paper on the one side of the tape, exposing 152.4 mm (6") of the rubberized asphalt, and then apply the rubberized asphalt side of the HYDRASTOP SA into this and roll press into place. Following this, remove the remaining release paper on the tape and apply the subsequent roll of HYDRASTOP SA into this area, making sure that both rolls are butted together. Roll press this into place. Following that, apply a 304.8 mm (12") band of POINTING MASTIC from W. R. MEADOWS onto this overlap at a thickness of approximately 60 mils, and embed DETAIL FABRIC from W. R. MEADOWS into this.

Please reference the END LAP TAPING METHOD TECHNICAL BULLETIN at www.wrmeadows.com for detailed visual installation instructions.

PRECAUTIONS

For vertical use only. During the entire application process, ensure that DETAIL TAPE V remains clean, free of any containments, dirt, dust, sand, etc. that will interfere with creating a watertight bond between DETAIL TAPE V and PRECON/HYDRASTOP SA

MASTERFORMAT NUMBER AND TITLE

07 13 00 – Sheet Waterproofing

For further LEED information and SDS, visit
www.wrmeadows.com.

2022-06-29

W. R. MEADOWS® OF CANADA
70 Hannant Court, Milton, ON L9T 5C1
21 Streambank Ave., Sherwood Park, AB T8H 1N1
(800) 342-5976
Montreal Sales: (514) 865-2406

Hampshire, IL / Cartersville, GA / York, PA / Fort Worth, TX
Benicia, CA / Pomona, CA / Goodyear, AZ / Milton, ON
Sherwood Park, AB
www.wrmeadows.com
info@wrmeadows.com