



TECHNICAL BULLETIN SPRAY ADHESIVES

Spray adhesives are a tool used to apply a wide variety of building materials, such as drain board, insulation board, and protection board to waterproofing, building envelope membranes and sealants. It is crucial to know which are chemically compatible and form strong adhesive bonds. A number of spray adhesives have now been tested and qualified for use with W. R. MEADOWS products and are shown in the table below.

		W. R. MEADOWS Membrane/Sealant									
		AIR-SHIELD LSR	AIR-SHIELD LMP	AIR-SHIELD TMP	AIR-SHIELD SMP	BEM	AIR-SHIELD LIQUID FLASHING	MEL-ROL LM	MEL-ROL	AIR-SHIELD	AIR-SHIELD BUTYL FLASHING
Spray Adhesive	● = Recommended for use by W. R. MEADOWS										
	Sta'-Put® Quick Grip*	●	●	●	●			●	●	●	●
	Sta'-Put Quick Grip LVOC*	●	●	●	●			●	●	●	●
	Tensorgrip® P323 Fast Dry Pressure Sensitive Adhesive*	●	●	●	●			●	●	●	●
	QDEK® QD2040 TPO/EPDM Membrane Adhesive	●	●	●	●			●	●	●	●
3M™ HoldFast 70 Spray Adhesive	●	●	●	●			●	●	●	●	
Adhesives marked with () are not recommended to be directly sprayed onto any kind of foam board. It is recommended to spray onto the W. R. MEADOWS membrane/sealant, wait until propellant has flashed off, then apply foam board to product.											

These recommendations are intended to assist the licensed design professional and the installer to understand compatibility. These recommendations do not supersede project specifications and are not standalone. All W. R. MEADOWS products must be installed per the appropriate drawings, details and literature. This document does not extend any approval for use beyond the provisions in W. R. MEADOWS published warranties.



W. R. MEADOWS, INC. | P.O. Box 338 | HAMPSHIRE, IL 60140-0338
 Phone: 847/214-2100 | Fax: 847/683-4544 | www.wrmeadows.com