



DETAILING NOTES:
 1) SCORCH & REMOVE THE TOP POLYFILM OF MEL-ROL TO EXPOSE THE UNDERLYING SBS ASPHALT IMMEDIATELY PRIOR TO APPLYING THE HRM 714 SYSTEM.

NOTE: DETAIL IS A GUIDE FOR INSTALLATIONS OF W. R. MEADOWS PRODUCTS ONLY. DETAIL MUST BE REVIEWED AND VERIFIED BY A DESIGN PROFESSIONAL FOR SUITABILITY ON THE PROJECT. W. R. MEADOWS DOES NOT ASSUME RESPONSIBILITY FOR ERRORS IN DESIGN OR ENGINEERING.

W. R. MEADOWS INC.
 300 INDUSTRIAL DR.
 HAMPSHIRE, IL 60140-0338
 1-800-342-5976



TITLE:
HRM 714 TRANSITION FROM MEL-ROL @ OUTSIDE CORNER EDGE (MEL-DRAIN)

SCALE: NTS
 DATE: JULY 9, 2020
 DWG NO.: HRM714- 03