



KNIGHTSHIELD® 5100
 (BLEED BLOCK PRIMER REQUIRED FOR EXISTING ASPHALT TYPE ROOFS -SEE NOTE #2)

PRETREAT EXISTING ROOF AND GUTTER FLASHING PRIOR TO **KNIGHTSHIELD® 5100** COATING INSTALLATION USING ONE OF THE METHODS BELOW:
 (STAIN BLOCKING PRIMER REQUIRED FOR EXISTING MB/BUR ROOFS -SEE NOTE #2)

- SEALANT (125 WET MILS)
 - **KNIGHTSHIELD® 5600**
- REINFORCED COATING (32 WET MILS)

EXISTING PREVIOUSLY COATED OR NON-COATED ROOFING ASSEMBLY
 EXISTING ROOF FLASHING

EXTEND **KNIGHTSHIELD® 5100** ONTO EXISTING GUTTER COMPLETELY ENCAPSULATING ALL SURFACES
 EXISTING GUTTER FLASHING

NOTES:

1. REFER TO **KNIGHTSHIELD® 5100** GUIDE SPECIFICATION, INSTALLATION MANUAL AND/OR APPLICATION GUIDE FOR RECOMMENDED INSTALLATION PROCEDURES.
2. INSTALL **KNIGHTSHIELD® 5900** BLEED-BLOCKING PRIMER ONTO EXISTING MB/BUR ROOF PRIOR TO FLASHING OR COATING INSTALLATION (BLEED-BLOCKING PRIMER NOT SHOWN FOR CLARITY).