



## DATA SHEET NO. 3042-000

# ULTRITE® COATING REMOVER

### DESCRIPTION

ULTRITE COATING REMOVER is an easy-to-use, soy-gel coating remover. This gel-type product effectively removes topical sealers, acrylics, latex, urethanes, enamels, some epoxies, and other single-component coatings. ULTRITE COATING REMOVER is safe, low-odour, and non-caustic.

The use of ULTRITE COATING REMOVER is the first step of a two-step coating removal process. The second step utilizes ULTRITE CLEANER from W. R. MEADOWS. ULTRITE CLEANER is used to remove the residues left from ULTRITE COATING REMOVER. For more details, refer to ULTRITE CLEANER #3041-000 data sheet.

### USES

When properly applied, ULTRITE COATING REMOVER will remove a wide range of one-part topical coatings such as curing and sealing compounds, acrylic sealers, polyurethanes, etc. The product can be applied to a variety of surfaces, including concrete, masonry, wood, and metal. The product is ideal for use in warehouses, industrial plants, food processing plants, schools, automotive plants, parking garages, plazas, and service stations.

### FEATURES/BENEFITS

- Easy to use.
- Removes many different types of coatings.
- Low odour.
- Environmentally friendly.

### PACKAGING

3.79 L (1 Gal.) Units (4/Cartron)  
18.93 L (5 Gal.) Pails  
208.2 L (55 Gal.) Drums

### COVERAGE

Horizontal: 3.06 m<sup>2</sup>/L (125 ft.<sup>2</sup>/gal.)  
Vertical: 1.84 m<sup>2</sup>/L (75 ft.<sup>2</sup>/gal.)

Coverage is approximate and may vary depending on coatings, concrete condition, climatic conditions, etc. Always apply to a test area first to determine actual coverage rate and softening time before full-scale application.

### SHELF LIFE

When stored indoors in original, unopened containers at temperatures between 4° - 32° C, optimum performance and best use is obtained within two years of date of manufacture.

### APPLICATION

**Application Method ...** Protect vegetation from product, splash, residue, and wind drift. Apply a thick, even layer of ULTRITE COATING REMOVER on the coating being removed. On horizontal surfaces, ULTRITE COATING REMOVER can be applied by rolling, brushing, squeegee, or airless sprayer. For large projects and vertical applications, use a commercial airless sprayer with a 0.019" - 0.021" (0.48 - .53 mm) nozzle and a spray rate of at least 2500 psi (17.2 MPa). An airless sprayer is the most effective way of applying ULTRITE COATING REMOVER.

ULTRITE COATING REMOVER must be applied 1.5 - 2 times thicker than the coating to be removed. The time needed for penetration of ULTRITE COATING REMOVER will vary depending on the type of coating and climatic conditions. Depending on type of coating, it may take up to 24 hours for proper softening and removal. A typical ASTM C309, Class B and/or ASTM C1315 sealer usually takes one hour for proper softening before removal, depending on application thickness.

Continued over ...

**W. R. MEADOWS OF CANADA**  
70 Hannant Court, Milton, ON L9T 5C1  
21 Streambank Ave., Sherwood Park, AB T8H 1N1  
(800) 342-5976  
Montreal Sales: (514) 865-2406

Hampshire, IL / Cartersville, GA / York, PA / Fort Worth, TX  
Benicia, CA / Pomona, CA / Goodyear, AZ / Milton, ON /  
Sherwood Park, AB  
[www.wrmeadows.com](http://www.wrmeadows.com)

The product should be kept moist once applied; do not allow product to dry. When used outdoors, cover material with 2-mil or thicker plastic to help keep the product wet and working.

Very thick and multiple-layer coatings may require a re-application of ULTRITE COATING REMOVER for proper removal.

Use a scraper to check if the coating is softened down to the surface. If not, wait longer and recheck. When the coating is completely softened, remove with a scraper, squeegee, or pressure wash. Material removed can be landfill-disposed when completely dry (no free liquids). Consideration must be given to the substrate/coating removed.

Always apply a test area prior to full scale application to determine coverage rate, suitability of the product for the coating and substrate, and time needed for the coating to be removed.

Substrate surface becomes extremely slippery after removal of the softened coating and ULTRITE COATING REMOVER. Once the softened coating and ULTRITE COATING REMOVER have been removed, ULTRITE CLEANER from W. R. MEADOWS and a final water rinse should be used to clean off remaining residue. Allow surface to dry before further preparations.

#### PRECAUTIONS

Keep from freezing. Surface becomes extremely slippery after removal of softened coatings and ULTRITE COATING REMOVER. ULTRITE CLEANER should be used to clean the surface and help reduce adhesion failure of subsequent coatings/treatments. Prior to application of subsequent coatings and/or treatments, ensure that there are no residues left from the ULTRITE COATING REMOVER and/or ULTRITE CLEANER application.

Do not use on PVC, drywall, limestone, plastic, veneer, terrazzo tile, or rubber. ULTRITE COATING REMOVER will destroy latex over time. After product application, rubber hoses of application equipment must be cleaned as the product will attack and damage the rubber. The product should be kept moist once applied; do not allow product to dry.

Failure to use ULTRITE CLEANER after ULTRITE COATING REMOVER will result in a hazardous, slippery surface.

#### ULTRITE CLEANER DIRECTIONS

##### APPLICATION

**Surface Preparation ...** Scrape off ULTRITE COATING REMOVER and softened coating from the surface before cleaning with ULTRITE CLEANER.

**Application Method ...** Protect vegetation, painted, stained and alkaline-sensitive surfaces from product, splash, residue, and wind drift. Apply ULTRITE CLEANER with a mop, broom, or sprayer. Allow the product to stay on the surface for 3 - 5 minutes before agitating with a brush or a mop. Rinse thoroughly with water. Using a pressure washer where possible is recommended for more effective results. Repeat the process as necessary. Do not allow the product to dry. Two rounds of cleaning is recommended for optimum results.

##### PRECAUTIONS

Do not dilute. Protect painted, stained, and alkaline-sensitive surfaces from ULTRITE CLEANER. Rinse well with water. Do not freeze. Product is not intended to be used by on its own – must be used in conjunction with ULTRITE COATING REMOVER.

##### MASTERFORMAT NUMBER AND TITLE

03 05 00 - Common Work Results for Concrete

##### LEED INFORMATION

May help contribute to LEED credits:

- MRC9: Construction and Demolition Waste Management

For most recent data sheet, further LEED information, and SDS, visit [www.wrmeadows.com](http://www.wrmeadows.com).

2018-07-10



® SEALTIGHT is a registered trade mark of W. R. Meadows

**WARRANTY:** W. R. Meadows of Canada warrants that, at the time and place we make shipment, our materials will be of good quality and will conform with our published specifications in force on the date of acceptance of the order. THE FOREGOING WARRANTY SHALL BE EXCLUSIVE AND IN LIEU OF ANY OTHER WARRANTY, EXPRESS OR IMPLIED, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND ALL OTHER WARRANTIES OTHERWISE ARISING BY OPERATION OF LAW, COURSE OF DEALING, CUSTOM OF TRADE OR OTHERWISE. As the exclusive remedy for breach of this Warranty, we will replace defective materials, provided, however, that the buyer examine the materials when received and promptly notify us in writing of any defect before the materials are used or incorporated into a structure. Three (3) months after W. R. Meadows of Canada has shipped the materials, all our Warranty and other duties with respect to the quality of the materials delivered shall conclusively be presumed to have been satisfied, all liability therefore terminates and no action for breach of any such duties may thereafter be commenced. W. R. Meadows of Canada shall in no event be liable for consequential damages. Unless otherwise agreed to in writing, no warranty is made with respect to materials not manufactured by W. R. Meadows of Canada. We cannot warrant or in any way guarantee any particular method of use or application or the performance of materials under any particular condition. Neither this Warranty nor our liability may be extended or amended by our salesmen, distributors or representatives, or by our distributor's representatives, or by any sales information or drawings.