



NO. 322

MasterFormat: 03 15 00



JUNE 2018
(Supersedes February 2014)

SPONGE RUBBER EXPANSION JOINT

Expansion/Contraction Control Joint

DESCRIPTION

SPONGE RUBBER EXPANSION JOINT is produced to a uniform thickness and density from gray-colored, top-quality, blown sponge rubber. It is easily compressed and has a recovery of 95% or more of the original thickness and a density of not less than 30 lb./ft.³ (480.56 kg/m³).

USES

SPONGE RUBBER EXPANSION JOINT is frequently used on bridge structures and sewage treatment plants that undergo rapid changes in temperature. Because of its excellent recovery capability during wide temperature variations, SPONGE RUBBER EXPANSION JOINT is used around supporting pillars, drains, hydrants, and lamp and sign posts, as well as in isolation applications or between materials having dissimilar coefficients of expansion.

FEATURES/BENEFITS

- High resiliency with excellent recovery after compression.
- Protects against water infiltration when properly sealed.
- Easy to handle and install.
- Offers isolation capabilities.

PACKAGING

Thickness Widths	Slab Widths	Standard Lengths
1/4" (6.35 mm) 3/8" (9.53 mm) 1/2" (12.7 mm) 3/4" (19.05 mm) 1" (25.4 mm)	36" (914.4 mm)	10' (3.05 m)

SPECIFICATIONS

- AASHTO M 153, Type I
- ASTM D 1752, Type 1
- Corps of Engineers CRD-C 509, Type I
- FAA Specification Item P-610-2.7
- Federal Specification HH-F-341 F, Type II, Class A

APPLICATION

The type of control joint and spacing used will vary with each project according to the type of structure, climatic conditions, and anticipated stresses in the concrete. Thinner joints of 1/4" (6.35 mm), 3/8" (9.53 mm), or 1/2" (12.7 mm), spaced at frequent intervals, offer greater control than thicker joints spaced at greater intervals. The basic objective is to provide ample room for the concrete to expand or contract without creating damaging stresses. Expansion joints should be positioned against forms at interrupting objects or columns and against abutting structures prior to the placement of the concrete. SPONGE RUBBER EXPANSION JOINT should be recessed 1/2" (12.7 mm) below the concrete surface to accept the joint sealant. To isolate filler from sealant, use SNAP-CAP[®] from W. R. MEADOWS.

DECK-O-SEAL[®], POURTHANE[™] NS, POURTHANE SL, and SOF-SEAL[®] are suitable sealants for horizontal applications of SPONGE RUBBER EXPANSION JOINT. The recommended sealants for vertical applications are DECK-O-SEAL GUN GRADE and POURTHANE NS.

PRECAUTIONS

Silicone sealants are not recommended for use with SPONGE RUBBER EXPANSION JOINT.

CONTINUED ON REVERSE SIDE ...

LEED INFORMATION

May help contribute to LEED credits:

- MRc9: Construction and Demolition Waste Management

For most current data sheet, further LEED information, and SDS, visit www.wrmeadows.com.



LIMITED WARRANTY

W. R. MEADOWS, INC. warrants at the time and place we make shipment, our material will be of good quality and will conform with our published specifications in force on the date of acceptance of the order. Read complete warranty. Copy furnished upon request.

Disclaimer

The information contained herein is included for illustrative purposes only, and to the best of our knowledge, is accurate and reliable. W. R. MEADOWS, INC. cannot however under any circumstances make any guarantee of results or assume any obligation or liability in connection with the use of this information. As W. R. MEADOWS, INC. has no control over the use to which others may put its product, it is recommended that the products be tested to determine if suitable for specific application and/or our information is valid in a particular circumstance. Responsibility remains with the architect or engineer, contractor and owner for the design, application and proper installation of each product. Specifier and user shall determine the suitability of products for specific application and assume all responsibilities in connection therewith.