

## PRECON® FABRIC TAPE

### DESCRIPTION

PRECON FABRIC TAPE is a self-adhering tape comprised of a rubberized asphalt waterproofing membrane laminated to a geotextile layer of non-woven polypropylene on one side and a release paper on the other.

### USES

PRECON FABRIC TAPE is used around pipe penetrations and end laps. The product can also be used on terminations, top edges of vertical applications, and perimeter terminations on horizontal applications. PRECON FABRIC TAPE can also be used as a detailing option with HYDRALASTIC 836 from W. R. MEADOWS in certain material and substrate transitions and over joints in plywood, cracks in concrete, etc.

### FEATURES/BENEFITS

- Non-woven side bonds to poured concrete.
- Self-adhesive side bonds to most surfaces.
- UV resistant.
- Self-adhesive.
- Compatible with HYDRALASTIC 836.

### PACKAGING

12" x 50' (30.48 cm x 15.24 m) Rolls, 4/Carton.  
Also available in cut rolls of 4" (102 mm), 6" (152 mm), and 9" (224 mm) wide by special order.

### APPLICATION

**Application Method ...** Remove release paper prior to application. Use firm hand pressure to ensure PRECON FABRIC TAPE is secured to surface and will not peel. Only remove as much release paper as needed to properly apply material. For best adhesion, MEL-PRIME™ or MEL-PRIME W/B from W. R. MEADOWS is recommended.

**Penetrations and Protrusions ...** Detail around all horizontal and vertical penetrations using MEL-ROL LIQUID MEMBRANE (two-component) from W. R. MEADOWS. Apply MEL-ROL LIQUID MEMBRANE (two-component) by forming a fillet around the pipe or protrusion, overlapping the fabric side of PRECON and the protrusion a minimum of 2 ½" (64 mm). If the gap between the protrusion and the membrane is greater than ½" (13 mm), apply PRECON FABRIC TAPE over the fully-cured two-component MEL-ROL LIQUID MEMBRANE (minimum 24 hours cure required). All penetration and protrusion surfaces must be clean, rust-free, and sound prior to application of MEL-ROL LIQUID MEMBRANE (two-component).

**End Laps ...** At terminations of PRECON, apply 12" (30.48 cm) wide area of PRECON FABRIC TAPE with 6" (15.2 cm) on each side of lap edge. For best results, use MEL-PRIME adhesive over 12" (30.48 cm) area prior to application of tape.

**Patching ...** Prior to placing concrete into area, inspect PRECON membrane for punctures or damage and repair as necessary with POINTING MASTIC from W. R. MEADOWS and/or additional PRECON FABRIC TAPE.

### LEED INFORMATION

May help contribute to LEED credits:

- EAp2: Minimum Energy Performance
- EAc2: Optimize Energy Performance
- MRc9: Construction and Demolition Waste Management

**For most recent data sheet, further LEED information and SDS, visit [www.wrmeadows.com](http://www.wrmeadows.com).**

*CONTINUED ON REVERSE SIDE...*



### **LIMITED WARRANTY**

W. R. MEADOWS, INC. warrants at the time and place we make shipment, our material will be of good quality and will conform with our published specifications in force on the date of acceptance of the order. Read complete warranty. Copy furnished upon request.

### **Disclaimer**

The information contained herein is included for illustrative purposes only, and to the best of our knowledge, is accurate and reliable. W. R. MEADOWS, INC. cannot however under any circumstances make any guarantee of results or assume any obligation or liability in connection with the use of this information. As W. R. MEADOWS, INC. has no control over the use to which others may put its product, it is recommended that the products be tested to determine if suitable for specific application and/or our information is valid in a particular circumstance. Responsibility remains with the architect or engineer, contractor and owner for the design, application and proper installation of each product. Specifier and user shall determine the suitability of products for specific application and assume all responsibilities in connection therewith.